#### BASIC ROUTER

Topology (LAN -- ROUTER -- MODEM -- INET)

LAN: 192.168.0.0/24 (dhcp-client)

ROUTER: int f0/0 192.168.1.1/30 | int f1/0 192.168.0.1/24


MODEM: 192.168.1.2/30

## 1. set password & hostname.

```
Router>enable
Router#configu
Router#configure
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#enable password 1234
Router(config)#hostname raisa
raisa(config)#
```

## 2. cek konfigurasi ya berjalan.





## 3. set ip interface fast ethernet 0/0.

```
raisa(config) #int f0/0
raisa(config-if) #ip address 192.168.1.1 255.255.252
raisa(config-if) # no shutdown

raisa(config-if) #
%LINK-5-CHANGED: Interface FastEthernet0/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface FastEthernet0/0, changed state to up

raisa(config-if) #
```


# 4. set ip interface fast ethernet 1/0.

```
raisa(config-if) #int f1/0
raisa(config-if) #ip address 192.168.0.1 255.255.255.0
raisa(config-if) #no shutdown

raisa(config-if) #
%LINK-5-CHANGED: Interface FastEthernet1/0, changed state to up

raisa(config-if) #
```

### 5. cek interface.



### 6. set dhcp-server int f1/0.

```
raisa#configure
Configuring from terminal, memory, or network [terminal]?
Enter configuration commands, one per line. End with CNTL/Z.
raisa(config)#ip dhcp pool raisa
raisa(dhcp-config)#network 192.168.0.0 255.255.255.0
raisa(dhcp-config)#default-router 192.168.0.1
raisa(dhcp-config)#dns-server 8.8.8.8
raisa(dhcp-config)#
```

### 7. set NAT & default route.

```
raisa(config) #access-list 1 permit 192.168.0.0 192.168.0.255

raisa(config) #ip nat pool inet 192.168.1.0 192.168.1.3 netmask 255.255.252

raisa(config) #ip nat inside source list 1 pool inet overload

raisa(config) #ip route 0.0.0.0 0.0.0 192.168.1.2

raisa(config) #int f0/0

raisa(config-if) #ip nat outside

raisa(config-if) #ip nat inside

raisa(config-if) #ip nat inside

raisa(config-if) #ip nat inside
```


#### 8. set name server.

```
raisa(config) #ip name-server 8.8.8.8
raisa(config) #
```

## 9. cek konfigurasi ya berjalan.

```
raisas show running-config
Building configuration: 1087 bytes

| version 12.2
| v
```



Dok 01/09/2015 padliyulian@ymail.com